



## ИБП Schneider Electric Galaxy VX - руководство по эксплуатации. Юниджет

Постоянная ссылка на страницу: <https://www.uni-jet.com/catalog/ibp/online-ibp/schneider-electric-galaxy-vx/>



# Galaxy VX

## UPS System

### Operation

06/2017



# Legal Information

The Schneider Electric brand and any registered trademarks of Schneider Electric Industries SAS referred to in this guide are the sole property of Schneider Electric SA and its subsidiaries. They may not be used for any purpose without the owner's permission, given in writing. This guide and its content are protected, within the meaning of the French intellectual property code (Code de la propriété intellectuelle français, referred to hereafter as "the Code"), under the laws of copyright covering texts, drawings and models, as well as by trademark law. You agree not to reproduce, other than for your own personal, noncommercial use as defined in the Code, all or part of this guide on any medium whatsoever without Schneider Electric's permission, given in writing. You also agree not to establish any hypertext links to this guide or its content. Schneider Electric does not grant any right or license for the personal and noncommercial use of the guide or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

As standards, specifications, and designs change from time to time, please ask for confirmation of the information given in this publication.

# Table of Contents

Important Safety Instructions — SAVE THESE INSTRUCTIONS .....	5
FCC Statement .....	6
Safety Precautions .....	6
Overview of UPS User Interface .....	7
Overview of Mimic Diagram .....	8
Overview of Status LEDs .....	8
Display Symbols .....	9
Operation Modes .....	10
UPS Operation Modes .....	10
System Operation Modes .....	13
UPS Display .....	15
UPS Display Menu Tree .....	15
Configuration from the UPS Display .....	16
Add a New User or Edit an Existing User .....	16
Delete a User .....	16
Configure the Display Preferences .....	17
Configure the Display Settings .....	17
Configure the UPS Output Voltage Compensation .....	18
Configure High Efficiency Mode .....	19
Configure the Input Contacts .....	20
Configure the Output Relays .....	21
Configure Reminder Settings .....	22
Configure Battery Alarm Threshold .....	23
Configure Automatic Battery Test .....	23
Configure the Network .....	24
Configure the Modbus .....	26
Restore Default Configuration .....	26
Operation Procedures from the UPS Display .....	27
Access Password-Protected Screens .....	27
View the System Status Information .....	27
Start Up Single System from Maintenance Bypass Operation .....	31
Shut Down Single System from Normal to Maintenance Bypass Operation .....	32
Transfer UPS from Normal to Requested Static Bypass Operation .....	33
Transfer UPS from Requested Static Bypass Operation to Normal Operation .....	33
Start Up Parallel System from Maintenance Bypass Operation .....	33
Shut Down Parallel System from Normal to Maintenance Bypass Operation .....	34
Start Up and Add UPS to a Running Parallel System .....	35
Isolate this Single UPS from the Parallel System .....	35
Start a Boost Charge of the Batteries .....	36
Access a Configured Network Management Interface .....	36
Troubleshooting from the UPS .....	37
Troubleshooting via the Mimic Diagram LEDs .....	37

- Reboot the Display ..... 38
- Logs ..... 38
- View the Active Alarms ..... 41
- Tests ..... 41
  - Perform a Battery Test ..... 41
  - Perform a Runtime Calibration ..... 42
  - Perform an Annunciators Test ..... 42
  - Calibrate the Display ..... 42
- 10" System Bypass Display** ..... 43
  - 10" System Bypass Display Menu Tree (Option) ..... 43
  - Configuration from the 10" System Bypass Display (Option) ..... 43
    - Configure the Display Settings ..... 43
    - Change the User Password ..... 44
    - Change the System Names ..... 45
    - Configure the Output Distribution Breakers ..... 46
  - Operation Procedures from the 10" System Bypass Display (Option) ..... 46
    - Access Password-Protected Screens ..... 46
    - View the Parallel System Status ..... 46
    - View System Bypass Status ..... 48
    - View UPS Status Information ..... 48
    - Transfer the Parallel System from Normal to Requested Static Bypass Operation ..... 51
    - Transfer the Parallel System from Requested Static Bypass to Normal Operation ..... 52
    - Connect to the 10" System Bypass Display Remotely ..... 52
  - Troubleshooting from the 10" System Bypass Display (Option) ..... 52
    - View the Display Log ..... 52
    - View the Parallel System Log ..... 53
    - View the Active Alarms ..... 54
- Maintenance** ..... 55
  - Replace the Top Filter ..... 55
  - Replace the Three Bottom Filters ..... 56
- Troubleshooting** ..... 57
  - Determine if you need a Replacement Part ..... 57
    - Find the Serial Numbers ..... 57
  - Return Parts to Schneider Electric ..... 57

# Important Safety Instructions — SAVE THESE INSTRUCTIONS

Read these instructions carefully and look at the equipment to become familiar with it before trying to install, operate, service or maintain it. The following safety messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety message indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages with this symbol to avoid possible injury or death.

## **DANGER**

**DANGER** indicates a hazardous situation which, if not avoided, **will result in death or serious injury**.

**Failure to follow these instructions will result in death or serious injury.**

## **WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, **could result in death or serious injury**.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

## **CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, **could result in minor or moderate injury**.

**Failure to follow these instructions can result in injury or equipment damage.**

## **NOTICE**

**NOTICE** is used to address practices not related to physical injury. The safety alert symbol shall not be used with this type of safety message.

**Failure to follow these instructions can result in equipment damage.**

## Please Note

Electrical equipment should only be installed, operated, serviced, and maintained by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

## FCC Statement

**NOTE:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Safety Precautions

### **⚠ DANGER**

#### **HAZARD OF ELECTRICAL SHOCK, EXPLOSION OR ARC FLASH**

All safety instructions in this document must be read, understood and followed.

**Failure to follow these instructions will result in death or serious injury.**

### **⚠ DANGER**

#### **HAZARD OF ELECTRICAL SHOCK, EXPLOSION OR ARC FLASH**


After the UPS system has been electrically wired, do not start up the system. Start-up must only be performed by Schneider Electric.

**Failure to follow these instructions will result in death or serious injury.**


# Overview of UPS User Interface

The user interface consists of:

- A. Display interface
- B. Status LEDs
- C. Mimic diagram
- D. Inverter ON button
- E. Inverter OFF button
- F. USB port for export of logs
- G. Display reset button
- H. Network connection LED:
  - Solid green: The system has valid TCP/IP settings.  
See *Configure the Network, page 24*.
  - Flashing green: The system does not have valid TCP/IP settings.
  - Solid orange: The display is inoperable. Contact Schneider Electric.
  - Flashing orange: The system is making BOOTP requests.  
See *Configure the Network, page 24*.
  - Alternately flashing green and orange: If the LED is alternately flashing slowly, the system is making DHCP requests.  
See *Configure the Network, page 24*.
  - If the LED is alternately flashing rapidly, the system is starting up.
  - Off: The display is not receiving input power or the display is inoperable.
- I. LED for indication of network connection type:
  - Solid green: The system is connected to a network operating at 10 Megabits per second (Mbps).
  - Flashing green: The system is receiving or transmitting data packets at 10 Megabits per second (Mbps).
  - Solid orange: The system is connected to a network operating at 100 Megabits per second (Mbps).
  - Flashing orange: The system is receiving or transmitting data packets at 100 Megabits per second (Mbps).
  - Off: One or more of the following exists: The display is not receiving input power, the cable that connects the system to the network is disconnected, the device that connects the system to the network is turned off, or the display is inoperable. Check the connections and if the LED remains off, contact Schneider Electric.
- J. Slots reserved for service.



## Overview of Mimic Diagram



The mimic diagram shows the power flow through the UPS system, and the status of the main functions.

Each LED can be in one of the below three states:


Green	The corresponding function is active and OK	
Red	The corresponding function is not working properly	
Off	The corresponding function is not active	

## Overview of Status LEDs

The status LEDs placed next to the display interface shows the current status of the UPS system:

     	<ul style="list-style-type: none"> <li>• Green: The load is protected</li> <li>• Green + Orange: The load is protected, but the system reports an alarm at warning level</li> <li>• Orange + Red: The load is unprotected and the system reports an alarm at warning level and an alarm at critical level</li> <li>• Red: The load is unprotected and the system reports an alarm at critical level</li> </ul>
---	--

## Display Symbols

Symbol	Description
	The locked home button appears when the system is locked by a password protection. Tap this button to go to the home screen of the display.
	The unlocked home button appears when the system has been unlocked using the password. Tap this button to go to the home screen of the display.
	Tap the OK button to confirm your selections and exit the current screen.
	Tap the ESC button to cancel your changes and exit the current screen.
	Tap the filter button to set up the filters for your logs.
	Tap the recycle bin button to clear the log.


# Operation Modes

The Galaxy UPS has two different levels of operation mode:

- UPS Operation Mode: The operation mode of the operated UPS. See *UPS Operation Modes, page 10.*
- System Operation Mode: The operation mode of the complete UPS system. See *System Operation Modes, page 13.*


## UPS Operation Modes

### Normal




During normal operation, the UPS supports the load with conditioned power. While the UPS is in normal operation, the input, inverter, and load LEDs are green, and the battery and bypass LEDs are off.

### Battery



If the utility/mains supply fails, the UPS transfers to battery operation and supports the load with conditioned power from the DC source. While the UPS system is in battery operation, the battery, inverter, and load LEDs are green, the bypass LED is off and the input LED is red.


### Requested Static Bypass



The UPS can be transferred to requested static bypass following a command from the display. During static bypass operation, the load is supplied from the bypass source. If a fault is detected, the UPS will transfer to normal operation or forced static bypass operation. If there is an interruption to the utility/mains power supply during requested static bypass operation, the system will transfer to battery operation.

During requested static bypass, the input, bypass and output LEDs are green and the battery and inverter LEDs are off.

## Forced Static Bypass



The UPS is in forced static bypass following a command from the UPS system or because the user has pressed the inverter OFF button on the UPS. During forced static bypass operation, the load is supplied directly by the bypass source.

During forced static bypass, the input, bypass and output LEDs are green and the battery and inverter LEDs are off or red if an alarm is present.

**NOTE:** The batteries are not available as an alternate power source while the UPS is in forced static bypass operation.

## Maintenance Bypass Operation

When the Maintenance Bypass Breaker (MBB) is closed, the UPS system enters maintenance bypass operation. The load is supplied with unconditioned power from the bypass input.

**NOTE:** The batteries are not available as an alternate power source while the UPS is in maintenance bypass operation.

## Static Bypass Standby

**NOTE:** Static bypass standby is only applicable to an individual UPS in a parallel system.

The UPS enters static bypass standby if the UPS is prevented from entering forced static bypass and the other UPS units of the parallel system can support the load.

In static bypass standby the output of the specific UPS is off.

The UPS automatically changes to the preferred operation mode when possible.

**NOTE:** If the other UPS units cannot support the load, the parallel system enters forced static bypass. The UPS in static bypass standby will then transfer to forced static bypass.

## Inverter Standby

**NOTE:** Inverter standby is only applicable to an individual UPS in a parallel system.

The UPS enters inverter standby if there is an interruption to the utility/mains supply of one UPS and the other UPS units of the parallel system can support the load with the configured redundancy level maintained. This is to avoid that the batteries are being drained in situations where it is not necessary.


## Battery Test

The UPS is in battery test mode when the UPS is performing a battery self-test or a runtime calibration.

**NOTE:** The battery test will be aborted if the utility/mains supply is interrupted or a critical alarm is present and will return to normal operation upon return of utility/ mains.

### ECO Mode

**NOTE:** ECO mode must be enabled by a Schneider Electric field service engineer.



ECO mode allows the UPS to be configured to use requested static bypass, with the load supplied through the bypass, as the preferred operation mode under predefined circumstances.

If a fault is detected (bypass voltage out of tolerance, output voltage out of tolerance, etc), the UPS will immediately change to normal operation or forced static bypass.


The main advantage of ECO mode is a reduction in the consumption of electrical power.

In case of interruption to the utility/mains supply, the UPS transfers to inverter operation for a continuous supply of the load.

The batteries are charged when the UPS is in ECO mode.

**NOTE:** When changes to ECO mode settings are made on one UPS in a parallel system, the settings are shared to all UPSs in the parallel system.

### ECOConversion Mode



ECOConversion allows the system to supply the active part of the load through the static bypass. The inverter is kept running in parallel with the bypass source and supplies the reactive part of the load.

The input power factor of the UPS is, regardless of the load power factor, maintained close to unity as the reactive part of the load is significantly reduced in the UPS input current.

In case of an interruption to the utility/mains supply, the inverter immediately maintains the output voltage so that breaks or drops during the transfer from ECOConversion mode are practically eliminated.

The batteries are charged when the UPS is in ECOConversion mode.

**NOTE:** When changes to ECOConversion settings are made on one UPS in a parallel system, the settings are shared to all UPSs in the parallel system.

### Self-test

After start-up of the UPS system, the UPS will perform an automatic self-test. The status and progress of the self-test are indicated by the flashing LEDs on the mimic diagram.

When the self-test has been passed, the LEDs will indicate the operation mode of the UPS system.

**NOTE:** If an LED continues to flash after completion of the self-test, please call Schneider Electric.

## Off

When the UPS is in off, the UPS does not supply the connected load with power.

## System Operation Modes

The system operation mode indicates the current output status of the complete UPS system and which source that supplies the load.

### Inverter

In inverter operation the load is supplied by the inverters. The UPS mode can be in either normal or battery operation when the system operation mode is inverter operation.

### Requested Static Bypass

When the system is in requested static bypass, the load is supplied from the bypass source. If a fault is detected, the system will transfer to inverter operation or forced static bypass operation.

### Forced Static Bypass

The system is in forced static bypass following a command from the UPS system or because the user has pressed the inverter OFF button on the UPS units. During static bypass operation, the load is supplied directly by the bypass source.

**NOTE:** The batteries are not available as an alternate power source while the system is in forced static bypass operation.

### Maintenance Bypass

In maintenance bypass operation, the load is supplied by unconditioned power from the bypass input via the maintenance bypass breaker.

**NOTE:** The batteries are not available as an alternate power source in maintenance bypass operation.

### ECO Mode

**NOTE:** ECO mode must be enabled by a Schneider Electric field service engineer.

ECO Mode allows the system to be configured to use requested static bypass, with the load supplied through the bypass, as the preferred operation mode under predefined circumstances.

The main advantage of ECO mode is a reduction in the consumption of electrical power.

In case of interruption to the utility/mains supply, the UPS transfers to inverter operation for a continuous supply of the load.

### ECOConversion Mode

ECOConversion allows the system to supply the active part of the load through the bypass. The inverter is kept running in parallel with the bypass source and supplies the reactive part of the load.

The input power factor of the UPS is, regardless of the load power factor, maintained close to unity as the reactive part of the load is significantly reduced in the UPS input current.


In case of an interruption to the utility/mains supply, the inverter immediately maintains the output voltage so that breaks or drops during the transfer from ECOnversion mode are practically eliminated. The behaviour is the same for all UPSs in the parallel system.

## Off

When the system operation mode is off, the UPS system does not supply the connected load with power.

# UPS Display


## UPS Display Menu Tree



## Configuration from the UPS Display

### Add a New User or Edit an Existing User

1. From the home screen on the display select **Configuration > Display > Security**.
2. Select **Add User** to add a new user or select **Edit User** to edit an existing user of the system.



The screenshot shows a navigation menu at the top with a home icon and buttons for Configuration, Display, Security, and Add User. The 'Add User' button is highlighted. Below the menu are three input fields labeled 'Name:', 'Pin:', and 'Confirm Pin:'. At the bottom right, there are two buttons labeled 'ESC' and 'OK'.

3. In the **Name** field, type in the name of the user. Complete with **Enter**.
4. In the **Pin** field, type in a pin code for the user. Complete with **Enter**.
5. In the **Confirm Pin** field, retype the pin code of the user. Complete with **Enter**.
6. Tap **OK** to save your settings.

### Delete a User

1. From the home screen on the display select **Configuration > Display > Security > Delete User**.
2. Browse to the user that you wish to delete using the up and down arrows and tap **OK**.
3. Tap **Yes** to confirm deletion of an existing user of the system.

## Configure the Display Preferences

1. From the home screen on the display select **Configuration > Display > Preferences**.

The screenshot shows the 'Preferences' screen with the following settings:

- Language: English
- Date Format: mm/dd/yyyy
- Temperature: US Customary (selected)
- Manual: (selected)
- Current Date: (empty field)
- Current Time: (empty field)
- Synchronize with NTP Server: (not selected)

Buttons: ESC, OK

2. Select the preferred language using the up and down arrows.
3. Select the preferred date format using the up and down arrows.
4. Select the preferred temperature units: US Customary (°Fahrenheit) or Metric (°Celsius).
5. Set the current date and time using one of the below two methods:
  - Set the date and time manually on the display by selecting **Manual** and typing the actual date and time and completing with **Enter**.
  - Set the date and time automatically by selecting **Synchronize with the NTP server** (Network Time Protocol server).

**NOTE:** NTP server settings can be configured in the network management interface via the Web.
6. Tap **OK** to save your settings.

## Configure the Display Settings

1. From the home screen on the display select **Configuration > Display > System Settings**.

The screenshot shows the 'System Settings' screen with the following settings:

- Alarm Volume: Low
- Button Volume: Medium
- Brightness: High
- Backlight Timeout:  Enable, 10 minutes
- Auto Log Off: 1 minutes
- Intensity: Off


Buttons: ESC, OK

2. Set the **Alarm Volume**. Choose between: **Off**, **Low**, **Medium**, and **High**.

3. Set the **Button Volume**. Choose between: **Off, Low, Medium, and High**.
4. Set the **Brightness** of the display. Choose between: **Low, Medium, and High**.
5. Enable or disable **Backlight Timeout**. If you wish to enable backlight timeout, set the time limit in minutes for enabling backlight timeout. Choose between: **60, 30, 10, 5, and 1**.
6. Set the intensity of the backlight. Choose between: **Off, Very Low, Low, and Medium**.
7. Set the time limit in minutes for automatic log off. Choose between: **60, 30, 10, 5, and 1**.
8. Tap **OK** to save your settings.


### Configure the UPS Output Voltage Compensation

1. From the home screen on the display select **Configuration > UPS > Output**.
2. Tap arrow to the right to go to the next output configuration screen.



3. Under **Voltage Compensation** select the preferred voltage compensation for your system. Choose between **-3%, -2%, -1%, 0%, 1%, 2%, or 3%**.

**NOTE:** This setting is shared between all UPSs in a parallel system.



4. Under **Output Voltage Compensation with Loaded Transformer** select the preferred output voltage compensation to compensate for load dependent transformer voltage drop. Choose between **0%**, **1%**, **2%**, or **3%**.

**NOTE:** This setting must be identical for all UPSs in a parallel system.

**NOTE:** When this setting is set to 0%, the output transformer voltage compensation is disabled.

5. Tap **OK** to confirm your setting.

## Configure High Efficiency Mode

**NOTE:** ECO Mode must be enabled by Schneider Electric during service configuration to make this selection available.


1. From the home screen on the display select **Configuration > UPS > High Efficiency Mode** and configure the following settings:

The screenshot shows a configuration menu with the following content:

- Home icon
- Configuration
- UPS
- High Efficiency Mode
- ECO Mode: Feature Disabled in Tuner
- Select High Efficiency Mode:  Disable
- ECO Mode
- EConversion
- EConversion Harmonics Compensator
- Navigation buttons: ESC, <, 1/2, >, OK

- a. **Select High Efficiency Mode:** Choose between **Disable**, **ECO Mode**, **EConversion**, and **EConversion Harmonics Compensator**.

2. Tap > and configure the schedule settings:




- a. **Schedule:** Select when the system should enter the selected EConversion or ECO mode. Choose between **Always**, **Programmed** and **Never**.
- b. **Active Schedules List:** If you chose **Programmed** above, select **Enable** and set the time and date for when the system should enter the selected EConversion or ECO mode.

3. Tap **OK** to confirm your settings.

### Configure the Input Contacts

1. On the display select **Configuration > Input Contacts** and select the input contact that you wish to configure.




2. Choose between the below options:

<b>Custom Input 1:</b> General purpose input.	<b>External Battery Monitor Detected Fault:</b> Input to indicate that the external battery monitor has detected a fault.
<b>Custom Input 2:</b> General purpose input.	<b>Battery Room Ventilation Inoperable:</b> Input to indicate that the battery room ventilation is inoperable. When the input is active, the battery charger will turn off.
<b>Ground fault:</b> Input to indicate that a ground fault is present.	<b>Supplied By Genset:</b> Input to indicate that the UPS is running on generator. The battery charge current will be reduced to the value set by Schneider Electric during start-up.
<b>Inhibit Transfer from Static Bypass:</b> When this input is active, and the system enters requested static bypass or forced static bypass, the system will be locked in static bypass as long as the input active.	<b>External energy storage monitoring minor alarm:</b> Input to indicate that the external energy storage monitor reports a minor alarm.
<b>External energy storage monitoring major alarm:</b> Input to indicate that the external energy storage monitor reports a major alarm.	<b>Force the Charger to Turn Off:</b> Input that forces the charger to turn off.
<b>Flywheel inoperable:</b> Input to indicate that the flywheel is inoperable.	<b>Disable High Efficiency Mode:</b> Input to disable the use of high efficiency mode

3. Tap **OK** to save your settings.

### Configure the Output Relays

1. On the display select **Configuration > Output Relays**.
2. Select to enable or disable **Energized check mode**.
  - When **Energized check mode** is enabled the output relays are ON. If a signal is received or the power supply to the relay is lost, the circuit will open and the relay will be deactivated.
  - When **Energized check mode** is disabled the output relays are OFF. If a signal is received, the circuit will close and the relay will be activated.



3. Select the output relay that you wish to configure.

4. Select the function that you wish to use the specific output relay for from the list below:

<b>Common Alarm:</b> The output is triggered when any alarm is present.	<b>Normal Operation:</b> The output is triggered when the UPS is running in normal operation.
<b>Battery Operation:</b> The output is triggered when the UPS is running in battery operation.	<b>Maintenance Bypass:</b> The output is triggered when the UPS is running in maintenance bypass operation.
<b>Static Bypass:</b> The output is triggered when the UPS is running in forced static bypass operation or requested static bypass operation.	<b>High Efficiency Mode:</b> The output is triggered when the UPS is running in EConversion or ECO mode.
<b>Output Overload:</b> The input is triggered when there is an overload condition.	<b>Fan Inoperable:</b> The output is triggered when one or more fans are inoperable.
<b>Battery is not Working Correctly:</b> The output is triggered when the batteries are not working correctly.	<b>Battery Disconnected:</b> The output is triggered when the batteries have been disconnected or the battery breaker(s) are open.
<b>Battery Voltage Low:</b> The output is triggered when the battery voltage is below the threshold.	<b>Input Out of Tolerance:</b> The output is triggered when the input is out of tolerance.
<b>Bypass Out of Tolerance:</b> The output is triggered when the bypass is out of tolerance.	<b>UPS Warning:</b> The output is triggered when a warning alarm is present.
<b>UPS Critical:</b> The output is triggered when a critical alarm is present.	<b>Parallel Redundancy Lost:</b> The output is triggered when the specified redundancy has been lost.
<b>External Fault:</b> The output is triggered when a fault external to the UPS is present.	<b>UPS Maintenance Mode:</b> The output is triggered when the unit output breaker (UOB) is open.
<b>System Warning:</b> The output is triggered when a warning alarm is present in a parallel system.	<b>System Critical:</b> The output is triggered when a critical alarm is present in a parallel system.
<b>System Common Alarm:</b> The output is triggered when any alarm is present in a parallel system.	<b>Emergency power off activated:</b> The output is triggered when the EPO has been activated.
<b>Transfer to static bypass disabled</b>	<b>UPS informational alarm:</b> The output is triggered when an information alarm is present.
<b>System informational alarm:</b> The output is triggered when an information alarm is present in a parallel system.	

- Set the delay in seconds for the specific output to activate. Select a value between 0 and 60 seconds.
- Tap **OK** to save your settings.

### Configure Reminder Settings

When the air filters have been replaced, the reminders settings must be updated.

- From the home screen on the display select **Configuration > Reminders**.

Configuration

Reminders

Reminders Signalling  Enable

Air Filter Check

Reminder:  Enable

Duration before 1st Reminder:  weeks [1 - 500]

Elapsed Time:  days [0 - 3650]

Remaining Time: 0 days

Remaining Reminders: 3

Reminder Status In progress

ESC
OK

2. Configure the following settings:
  - a. **Reminders Signalling:** Select **Enable** to enable the display of all reminders.
  - b. **Reminder:** Select **Enable** to enable the display of reminders for air filter replacement.
  - c. **Duration before 1st Reminder:** Set the time in weeks before the first reminder is shown.
  - d. **Elapsed Time:** Manually set the number of days that the air filters have been used.
3. Tap **OK** to confirm your settings.

## Configure Battery Alarm Threshold

1. From the home screen on the display select **Configuration > Battery > Alarms**.

The screenshot shows a navigation bar at the top with three tabs: 'Configuration', 'Battery', and 'Alarms'. The 'Alarms' tab is selected. Below the navigation bar, the text reads: 'Low Battery Shutdown Level: 1.60 V/cell' and 'Low battery alarm threshold: 240 sec [60 - 600]'. The value '240' is entered in a text box. At the bottom right, there are two buttons: 'ESC' and 'OK'.

2. Select your preferred battery alarm threshold in seconds. Select a value between 60 and 6000 seconds and complete with **Enter**.
3. Tap **OK** to confirm your setting.

## Configure Automatic Battery Test

1. From the home screen on the display select **Configuration > Battery > Test**.

The screenshot shows a navigation bar at the top with three tabs: 'Configuration', 'Battery', and 'Test'. The 'Test' tab is selected. Below the navigation bar, there are three settings: 'Battery Test Interval: Every 8 Weeks', 'Battery Test Start Time: 0h 0m', and 'Battery Test Day of the Week: Tuesday'. Each setting has a dropdown arrow on the left and a dropdown arrow on the right. At the bottom right, there are two buttons: 'ESC' and 'OK'.

2. Set your preferred settings for the automatic battery test:
  - a. **Battery Test Interval:** Select your preferred interval for battery tests. Choose between: **Never, Every 52 Weeks, Every 26 Weeks, Every 12 Weeks, Every 8 Weeks, Every 4 weeks, Every 2 Weeks, or Once a Week.**  
  
**NOTE:** If you run battery tests too frequently it can reduce the lifetime of the batteries.
  - b. **Battery Test Start Time:** Select the time of the day in 24 hour format that the test should take place and complete with **Enter**.
  - c. **Battery Test Day of the Week:** Select the day of the week that the test should take place and complete with **Enter**.
3. When all settings have been completed, tap **OK** to confirm your settings.

## Configure the Network

The network can be configured for the display and for the cards in Smart Slot 1 and Smart Slot 2.

1. From the home screen on the display select **Configuration > Network** and select either **Display, Smart Slot 1, or Smart Slot 2** if present.
2. Configure the following settings:
  - a. **TCP/IPv4: Enable IPv4** (if applicable), and select the **Address Mode (Manual, DCHP, or BOOTP)**.

The screenshot shows a configuration menu with a home icon and tabs for Configuration, Network, Display, and TCP/IPv4. The 'TCP/IPv4' tab is active. It features a checked 'Enable IPv4' option. Under 'Address Mode', 'DHCP' is selected with up/down arrow buttons. There is an unchecked checkbox for 'Require vendor specific cookies to accept DHCP'. Below this is a 'Manual Settings' section with three rows: 'System IP', 'Subnet Mask', and 'Default Gateway', each with a text input field containing '0.0.0.0' and a secondary '0.0.0.0' label. 'ESC' and 'OK' buttons are at the bottom right.

- b. **TCP/IPv6: Enable IPv6** (if applicable), select **Auto Configuration** or **Manual Configuration**, and select the **DHCPv6 Mode (Router controlled, Non-Address Information Only, Never, or Address and Other Information)**.

**NOTE:** Tap **Addresses** to see all valid IPv6 addresses.

- c. **Web Access: Enable Web** (if applicable) and select the **Access Mode (HTTP or HTTPS)**.

**NOTE:** Not available for Smart Slots.

- d. **FTP server: Enable FTP** (if applicable).


**NOTE:** Not available for Smart Slots.

### Configure the Modbus

The modbus can be configured for the display and for the cards in Smart Slot 1 and Smart Slot 2.

**NOTE:** Only the display and optional Network Management Card AP9635 can be used for serial modbus.


1. From the home screen on the display select **Configuration > Modbus** and select either **Display, Smart Slot 1,** or **Smart Slot 2.**
2. Configure the modbus by enabling **Serial** or **TCP** access, and adding the needed values.



3. Tap **OK** to confirm your settings.

### Restore Default Configuration

1. From the home screen on the display select **Configuration > Restore Defaults.**



2. Select one of the below options:
  - **Restart Network Interface:** Select this option to restart network interface.
  - **Reset All:** Select this option to reset all settings to default. You can select to leave out the TCP/IP settings from the reset procedure.
  - **Reset Only:** Select this option if you only wish to reset parts of the settings to default values. You can select to reset the following settings: **TCP/IP, Event Configuration,** and **Display Settings.**

- When you have made your selection, tap **OK** to reset the selected settings to default.

## Operation Procedures from the UPS Display

### Access Password-Protected Screens

V				Λ
Pin				
[Input Field]				
1	2	3	±	
4	5	6	:	
7	8	9	.	
0	ESC	DEL	↩	

- When prompted for the password, select your username.
- Type in the pin code for your username.

**NOTE:** The default pin code is 1234.

### View the System Status Information

- From the home screen on the display select **Status**.
- Select the area for which you wish to see the status. Choose between:

#### Input

<b>Voltage</b> (phase-to-neutral) <sup>1</sup>	The present phase-to-neutral input voltage in volts (V).
<b>Current</b>	The present input current from the AC utility power source per phase in amperes (A).
<b>Maximum RMS Current</b>	The maximum current for the latest 30 days.
<b>Apparent Power</b>	The present apparent power input for each phase in kVA. Apparent power is the product of RMS (root mean square) volts and RMS amperes.
<b>Active Power</b>	The present active power (or real power) input for each phase in kilowatts (kW). Active power is the portion of power flow that, averaged over a complete cycle of the AC waveform, results in net transfer of energy in one direction.
<b>Power Factor</b>	The ratio of the active power to apparent power.
<b>Voltage</b> (phase-to-phase)	The present phase-to-phase input voltage.
<b>Total Apparent Power</b>	The present total apparent power input (for all three phases) in kVA.
<b>Total Active Power</b>	The present total active power input (for all three phases) in kW.
<b>Frequency</b>	The present input frequency in hertz (Hz).
<b>Energy</b>	The total energy consumption since the time of installation or since the number was reset.

<sup>1</sup> Only applicable in systems with neutral connection.

**Output**

<b>Voltage</b> (phase-to-neutral) <sup>2</sup>	The phase-to-neutral output voltage at the inverter in volts (V).
<b>Current</b>	The present output current for each phase in amperes (A).
<b>Maximum RMS Current</b>	The maximum current for the latest 30 days.
<b>Apparent Power</b>	The present apparent power output for each phase in kVA. Apparent power is the product of RMS (root mean square) volts and RMS amperes.
<b>Active Power</b>	The present active power (or real power) output for each phase in kilowatts (kW). Active power is the portion of power flow that, averaged over a complete cycle of the AC waveform, results in net transfer of energy in one direction.
<b>Power Factor</b>	The present output power factor for each phase. Power factor is the ratio of active power to apparent power.
<b>Current Crest Factor</b>	The present output crest factor for each phase. The output crest factor is the ratio of the peak value of the output current to the RMS (root mean square) value.
<b>Current THD</b>	The THD (total harmonic distortion) for each phase, as a percentage, for the present output current.
<b>Voltage</b> (phase-to-phase)	The phase-to-phase output voltage at the inverter in volts (V).
<b>Total Apparent Power</b>	The present apparent power output for each phase in thousands of Volt-Amps (kVA). Apparent power is the product of RMS (root mean square) volts and RMS amperes.
<b>Total Active Power</b>	The present total active output power (for all three phases) in kilowatts (kW).
<b>Load</b>	The percentage of the UPS capacity presently used across all phases. The load percentage for the highest phase load is displayed.
<b>Neutral Current</b> <sup>2</sup>	The present output neutral current in amperes (A).
<b>Frequency</b>	The present output frequency in hertz (Hz).
<b>Inverter Status</b>	The general condition of the inverter.
<b>PFC Status</b>	The general condition of the PFC.
<b>Energy</b>	The total energy supplied since the time of installation or since the value was reset.

2. Only applicable in systems with neutral connection.

## Bypass

<b>Voltage</b> (phase-to-neutral) <sup>3</sup>	The present phase-to-neutral bypass voltage (V).
<b>Current</b>	The present bypass current for each phase, in amperes (A).
<b>Maximum RMS Current</b>	The maximum current for the latest 30 days.
<b>Apparent Power</b>	The present apparent bypass power for each phase in kVA. Apparent power is the product of RMS (root mean square) volts and RMS amperes.
<b>Active Power</b>	The present active bypass power for each phase in kilowatts (kW). Active power is the time average of the instantaneous product of voltage and current.
<b>Power Factor</b>	The present bypass power factor for each phase. Power factor is the ratio of active power to apparent power.
<b>Voltage</b> (phase-to-phase)	The present phase-to-phase bypass voltage (V).
<b>Total Apparent Power</b>	The present total apparent bypass power (for all three phases) in thousands of Volt-Amps (kVA).
<b>Total Active Power</b>	The present total active bypass power (for all three phases) in kilowatts (kW).
<b>Frequency</b>	The present bypass frequency in hertz (Hz).

## Battery

<b>Voltage</b>	The present battery voltage.
<b>Current</b>	The present battery current in amperes (A). A positive current indicates that the battery is charging; a negative current indicates that the battery is discharging.
<b>Power</b>	The present DC power being drawn from the battery, in kilowatts (kW).
<b>Estimated Charge Level</b>	The present battery charge, as a percentage of full charge capacity.
<b>Estimated Charge Time</b>	The estimated time, in minutes, until the batteries reach 100% charge.
<b>Runtime Remaining</b>	The amount of time in hours and minutes before the batteries reach the low-voltage shutdown level.
<b>Charger Mode</b>	The operation mode of the charger (Off, Float, Boost, Equalization, Cyclic, Test).
<b>Battery Status</b>	The general condition of the battery.
<b>Charger Status</b>	The general condition of the charger.
<b>Total Battery Capacity</b>	The total capacity available from the available batteries.
<b>Temperature</b>	The highest battery temperature from the connected temperature sensors.

## Temperature

<b>Ambient Temperature</b>	Ambient temperature in degrees Celsius or Fahrenheit for the I/O cabinet and each power cabinet.
----------------------------	--

3. Only applicable in systems with neutral connection.

## System

<b>Output Voltage</b>	The phase-to-phase output voltage at the inverter in volts (V).
<b>Output Current</b>	The present output current for each phase in amperes (A).
<b>Output Frequency</b>	The present output frequency in hertz (Hz).
<b>Runtime Remaining</b>	The amount of time in hours and minutes before the batteries reach the low-voltage shutdown level.
<b>System Time</b>	The time of the UPS system.
<b>UPS Operation Mode</b>	The operation mode of the operated UPS.
<b>System Operation Mode</b>	The operation mode of the complete UPS system.
<b>Total Output Power</b>	The apparent and active power (or real power) output for each phase.
<b>Output Power</b>	The phase-to-phase apparent and active power (or real power) output for each phase.

## Parallel System

<b>Input Current</b>	The present phase-to-phase input current in amperes (A).
<b>Output Current</b>	The present phase-to-phase output current in amperes (A).
<b>Bypass Current</b>	The present phase-to-phase bypass current in amperes (A).
<b>Parallel UPS Number</b>	The parallel UPS number of the operated UPS.
<b>Parallel system redundancy</b>	The redundancy for the parallel system.
<b>Number of Parallel Units</b>	The total number of UPSs in the parallel system.
<b>Parallel Units</b>	The numbers of all UPSs in the parallel system.
<b>Output Total Apparent Power</b>	The present total apparent output power (for all three phases) in thousands of Volt-Amps (kVA).
<b>Output Total Load</b>	The percentage of the UPS system capacity presently used across all phases. The load percentage for the highest phase load is displayed.

## Active Alarms


<b>Active Alarms</b>	For more information on active alarms, go to <i>View the Active Alarms, page 41</i> .
----------------------	---

## Mimic Diagram

<b>Mimic Diagram</b>	The mimic diagram shows the current status of the main parts of the UPS system: power sources, converters, bypass static switch and breakers, and it shows the power flow through the system.
----------------------	---

## Detailed View

<b>Detailed view</b>	The detailed view shows the system with a status icon on each individual power cabinet and the actual number of redundant power cabinets. The detailed view also shows the apparent power and active power per phase.
----------------------	---



### Symbols on the Detailed View Screen

	Indicates that the power cabinet is operational and working correctly
	Indicates that there is an informational alarm.
	Indicates that the power cabinet redundancy has been lost and/or an alarm of severity level <b>Warning</b> is present in the power cabinet. The power cabinet is still operational.
	Indicates that the power cabinet is inoperable due to a critical event. The customer alarm <b>Power cabinet inoperable</b> is also displayed.

3. Tap the home button to exit the screens and return to the home screen.

### Start Up Single System from Maintenance Bypass Operation

Use this procedure to start up a single system from maintenance bypass operation with the load supplied through the MBB and all other breakers open.

**NOTE:** Only operate a breaker when the associated breaker LED is green.

1. Close the unit input breaker UIB.  
This will power up the display interface after approximately 30 seconds.
2. From the home screen on the display, select **Control > Startup Wizard**. Select **Startup from Maintenance Bypass** and follow the steps which appear on the screen.  
The following is a generic start-up procedure. Always follow the steps of the **Startup Wizard** which are specific to your system.
3. Close the static switch input breaker SSIB.
4. Close the backfeed protection switch (BF2) if it is open.
5. Close the battery breakers in your specific battery solution.

6. Initiate transfer to static bypass by tapping the **Transfer Load to static bypass** button on the display interface.

In systems with kirk-keys, the key is released from the solenoid key release unit.

If the UPS system does not transfer to requested static bypass, go to **Status > Active Alarms** to see if there are active alarms that prevent the UPS system from transferring to static bypass.

7. In systems with kirk-keys, insert the key in the lock on the unit output breaker UOB and turn to unlock.
8. Close the unit output breaker UOB.
9. Open the maintenance bypass breaker MBB.  
The system automatically transfers to normal operation.
10. In systems with kirk-keys, turn the key in the lock of the maintenance bypass breaker MBB to lock open.  
The key is released.
11. In systems with kirk-keys, insert the key in the solenoid key release unit and turn to capture the key.

## Shut Down Single System from Normal to Maintenance Bypass Operation

Use this procedure to shut down a single system to maintenance bypass operation with the load supplied through the MBB.

**NOTE:** Only operate a breaker when the associated breaker LED is green.

1. From the home screen on the display, select **Control > Shutdown Wizard**. Select **Shutdown ending in Maintenance Bypass** and follow the steps which appear on the screen.

**NOTE:** The following is a generic shutdown procedure. Always follow the steps of the **Shutdown Wizard** which are specific to your system.

2. Initiate transfer to static bypass by tapping the **Transfer Load to static bypass** button on the display interface.


In systems with kirk-keys, the key is released from the solenoid key release unit.

If the UPS system does not transfer to requested static bypass, go to **Status > Active Alarms** to see if there are active alarms that prevent the UPS system from transferring to static bypass.

3. In systems with kirk-keys, insert the key in the lock on the maintenance bypass breaker MBB and turn to unlock.
4. Close the maintenance bypass breaker MBB.  
In systems with kirk-keys, the key is held in the lock.
5. Open the unit output breaker UOB.
6. In systems with kirk-keys, turn the key in the lock on the unit output breaker UOB to lock open.  
The key is released.
7. In systems with kirk-keys, insert the key in the solenoid key release unit and turn to capture the key.
8. Initiate transfer to forced static bypass by tapping the Inverter OFF button on the front of the UPS system.
9. Open the static switch input breaker SSIB.
10. Open the battery breakers in your specific battery solution.
11. Open the unit input breaker UIB.

## Transfer UPS from Normal to Requested Static Bypass Operation

1. From the home screen on the display select **Control > Operational Mode**.




2. Tap the **Transfer to Requested Static Bypass** button.

**NOTE:** If the conditions for performing a transfer are not met, the button will be grayed out.

3. Verify that the **UPS Operation Mode** changes to **Requested Static Bypass**.

## Transfer UPS from Requested Static Bypass Operation to Normal Operation

1. From the home screen on the display select **Control > Operational Mode**.



2. Tap the **Transfer to Inverter Operation** button.

**NOTE:** If the conditions for performing a transfer are not met, the button will be grayed out.

3. Verify that the **UPS Operation Mode** changes to **Normal Operation**.

## Start Up Parallel System from Maintenance Bypass Operation

Use this procedure to start up a parallel system from maintenance bypass operation with the load supplied through the MBB and all other breakers open.

**NOTE:** Only operate a breaker when the associated breaker LED is green.

1. Close the unit input breaker UIB.  
This will power up the display interface after approximately 30 seconds.
2. From the home screen on the display, select **Control > Startup Wizard**.  
Select **Startup from Maintenance Bypass** and follow the steps which appear on the screen.

**NOTE:** The following is a generic start-up procedure. Always follow the steps of the **Startup Wizard** which are specific to your system.

3. Close the static switch input breaker SSIB.
4. Close the backfeed protection switch (BF2) if it is open.
5. Close the battery breakers in your specific battery solution.
6. Initiate transfer to static bypass by tapping the **Transfer Load to static bypass** button on the display interface.

In systems with kirk-keys, the key is released from the solenoid key release unit.

If the UPS system does not transfer to static bypass, go to **Status > Active Alarms** to see if there are active alarms that prevent the UPS system from transferring to static bypass.

7. Close the unit output breaker UOB.
8. Repeat steps 1 to 7 for the remaining UPS units in the parallel system before continuing.
9. In systems with kirk-keys, insert the key from the solenoid key release unit in the lock on the system isolation breaker SIB and turn to unlock.
10. Close the system isolation breaker SIB.
11. Open the maintenance bypass breaker MBB.  
The system automatically transfers to normal operation.
12. In systems with kirk-keys, turn the key in the lock of the maintenance bypass breaker MBB to lock open.  
The key is released.
13. In systems with kirk-keys, insert the key in the solenoid key release unit and turn to capture the key.

## Shut Down Parallel System from Normal to Maintenance Bypass Operation

Use this procedure to shut down a parallel system to maintenance bypass operation with the load supplied through the MBB.

**NOTE:** Only operate a breaker when the associated breaker LED is green.

1. From the home screen on the display, select **Control > Shutdown Wizard**.  
Select **Shutdown ending in Maintenance Bypass** and follow the steps which appear on the screen.

**NOTE:** The following is a generic shutdown procedure. Always follow the steps of the **Shutdown Wizard** which are specific to your system.

2. Initiate transfer to static bypass by tapping the **Transfer Load to static bypass** button on the display interface.

In systems with kirk-keys, the key is released from the solenoid key release unit in the system bypass cabinet.

If the UPS system does not transfer to requested static bypass, go to **Status > Active Alarms** to see if there are active alarms that prevent the UPS system from transferring to static bypass.

3. Close the maintenance bypass breaker MBB.  
In systems with kirk-keys, the key is held in the lock.

4. Open the system isolation breaker SIB.
5. In systems with kirk-keys, turn the key in the lock on the system isolation breaker SIB to lock open.  
The key is released.
6. In systems with kirk-keys, insert the key in the solenoid key release unit and turn to capture the key.
7. Perform the following steps for each UPS unit in the parallel system:
  - a. Open the unit output breaker UOB.
  - b. Initiate transfer to forced static bypass by tapping the Inverter OFF button on the front of the UPS system.
  - c. Open the static switch input breaker SSIB.
  - d. Open the battery breakers in your specific battery solution.
  - e. Open the unit input breaker UIB.

## Start Up and Add UPS to a Running Parallel System

Use this procedure to start up a UPS and add it to a running parallel system.

**NOTE:** Only operate a breaker when the associated breaker LED is green.

1. Close the unit input breaker UIB.  
This will power up the display interface after approximately 30 seconds.
2. From the home screen on the display, select **Control > Startup Wizard**.  
Select **Startup UPS into a parallel system** and follow the steps which appear on the screen.

**NOTE:** The following is a generic start-up procedure. Always follow the steps of the Startup Wizard which are specific to your system.

3. Close the static switch input breaker SSIB.
4. Close the backfeed protection switch (BF2) if it is open.
5. Close the battery breakers in your specific battery solution.
6. Close the unit output breaker UOB.
7. Turn the inverter on by tapping the Inverter ON button on the front of the UPS.

## Isolate this Single UPS from the Parallel System

Use this procedure to shut down one UPS in a running parallel system.

**NOTE:** Before initiating this procedure, ensure that the remaining UPS units can supply the load.

**NOTE:** Only operate a breaker when the associated breaker LED is green.

1. From the home screen on the display, select **Control > Shutdown Wizard**.  
Select **Shut down UPS in a parallel system** and follow the steps which appear on the screen.

**NOTE:** The following is a generic shutdown procedure. Always follow the steps of the Shutdown Wizard which are specific to your system.

2. Turn off the UPS by pressing the Inverter OFF key on the front of the UPS.
3. Open the unit output breaker UOB.
4. Open the static switch input breaker SSIB.
5. Open the battery breakers in your specific battery solution.


6. Open the unit input breaker UIB.

### Start a Boost Charge of the Batteries

Boost charge gives the possibility of doing a fast recharge of a discharged battery.

**NOTE:** Boost charge must be enabled by Schneider Electric during start-up for this option to be available.

1. From the home screen on the display select **Control > Charger Mode**.



2. Select **Boost Charge** to initiate a single boost charge of the batteries.

The UPS system starts boost charging the batteries.

To stop the boost charge and go back to float charge, select **Float Charge**.

### Access a Configured Network Management Interface

The below procedure describes how to access the network management interface from a web interface. It is also possible to use the following interfaces:

- Telnet and SSH
- SNMP
- FTP
- SCP

**NOTE:** Ensure that only one network management interface in the entire system is set to synchronize time.

Use Microsoft Internet Explorer® 7.x or higher on Windows operating systems only or Mozilla® Firefox® 3.0.6 or higher on all operating systems to access the web interface of the network management interface. Other commonly available browsers may work but have not been fully tested.

You can use either of the following protocols when you use the web interface:

- The HTTP protocol (enabled by default), which provides authentication by user name and Pin but no encryption.
- The HTTPS protocol, which provides extra security through Secure Socket Layer (SSL); encrypts user names, Pin, and data being transmitted; and authenticates Network Management Cards by means of digital certificates.

1. Access the network management interface by its IP address (or its DNS name, if a DNS name is configured).
2. Enter the user name and password.


- To enable or disable the HTTP or HTTPS protocol, use the **Network** menu on the **Administration** tab, and select the **Access** option under the **Web** heading on the left navigation menu.

## Troubleshooting from the UPS

### Troubleshooting via the Mimic Diagram LEDs

The mimic diagram shows the status of the main functions and the energy flow supplying the load. The different LEDs are either green, red or turned off depending on the status of the system functions. In this section it is listed what a red LED on the mimic diagram is indicating to help troubleshooting.


#### Input LED



If the input LED is red, it can be caused by the following:

- UIB is open
- Input out of tolerance (waveform-, voltage-, or frequency out of tolerance)


#### Inverter LED



If the inverter LED is red, it can be caused by the following:

- Inverter inoperable


#### Load LED



If the load LED is red, it can be caused by the following:

- UOB is open
- SIB is open
- Output voltage out of tolerance


#### Battery LED



If the Battery LED is red, it can be caused by the following:

- Critical battery alarm active
- Charger inoperable
- Battery breaker disconnected

### Bypass LED




If the bypass LED is red, it can be caused by the following:

- SSIB is open
- Static bypass switch inoperable
- Bypass out of tolerance
- BF2 is open

## Reboot the Display

**NOTE:** A reboot of the display does not impact the settings made.

1. Open the shutter door on the front right side of the display.
2. Press the reboot button with a pointed object like a pen or a paper clip.



The display is rebooted.

## Logs


There are two types of logs:

- NMC Log: Contains information about the display and network activities.
- UPS Log: Contains information about the system status and operation modes.

### View the NMC Log


1. From the home screen on the display select **Logs > NMC Log**.

2. You can browse through the list of the events using the arrows.



3. You can now perform the following operations in the event log:

a. Tap the filter button to filter the events. Different filter settings are available, including:



Filters for **Power Events**: **Communication, Device, Output, Input, Battery, UPS Operation Mode, Parallel System, Reminders, Switchgear, and/or RFC 1628 MIB.**

Filters for **System Events**: **Mass Configuration and/or Security.**

b. Tap the recycle bin button to clear the event log and select **Yes** to confirm.

4. Tap the home button to exit the log.

### View the UPS Log

1. From the home screen on the display select **Logs > UPS Log**.

Date/Time		Event	
XX:XX:XX	XX/XX/XXXX		


🗑️
⏪
⏴
1 / 16
⏵
⏩
⏴

2. You can now browse through the list of the UPS events using the arrows.
3. You can perform the following operations in the UPS log:
  - a. Tap the filter button to filter the events. Different filter settings are available, including:  
  
 Filters for **Power Events: Communication, Device, Output, Input, Battery, UPS Operation Mode, Parallel System, Reminders, Switchgear,** and/or **RFC 1628 MIB.**  
  
 Filters for **System events: Mass Configuration** and/or **Security.**
  - b. Tap the recycle bin button to clear the UPS log and select **Yes** to confirm.
4. Tap the home button to exit the log.

### Export Data from Logs

The exported log can only be used by Schneider Electric customer support for analysis.

1. From the home screen on the display select **Logs > Export Data**.
2. Insert a USB device in the USB port located on the front of the display.



3. Tap the **Start Data Export** button.

When the download is complete, the following message will be shown on the screen: **Data Exported Successfully. Remove USB device.**

4. Remove the USB device and tap the home button to exit the screen.
5. The exported data on the USB device can now be sent to Schneider Electric support for analyzing.

## View the Active Alarms

When there is an active alarm in the system, a symbol indicating the alarm level is shown in the top right corner of the screen and the buzzer is active.

1. From the home screen on the display select **Status > Active Alarms**. Tapping the display will also silence the buzzer temporarily without login. By logging in and tapping the display, the buzzer will be silenced permanently.
2. You can now browse through the list of active alarms using the left and right arrows.
3. Tap the **Refresh** button to update the list with the latest active alarms.

### Alarm Levels

There are three alarm levels:

- **Critical:** Take immediate action and call Schneider Electric.
- **Warning:** The load remains supported, but action must be taken. Call Schneider Electric.
- **Informational:** No immediate action required. Check the cause of the alarm as soon as possible.

## Tests

The UPS system can perform the following tests to ensure correct performance of the system:

- **Battery Test**
- **Runtime Calibration**
- **Annunciators**
- **Display Calibration**

### Perform a Battery Test

Prerequisites:

- The batteries must be more than 50% charged.
- The runtime available must be more than 4 minutes.
- The operation mode must be normal operation, ECONversion, or ECO mode.
- The system operation mode must be normal, ECONversion, or ECO mode.

This feature performs a number of tests on the batteries, such as fuse-blown check, weak battery detection. The test will discharge the battery, and use about 10% of the total capacity. Meaning if you have 10 minutes of runtime, the test will run for 1 minute. The **Battery Test** can be set up to run automatically in different time intervals (from weekly and up to once a year).

1. From the home screen on the display select **Tests > Battery Test**.
2. Tap the **Start Battery Self-Test** button.

**NOTE:** If you wish to manually stop the battery self-test, tap the **Abort Battery Self-Test** button.

## Perform a Runtime Calibration

This feature is used for calibrating the estimated remaining battery runtime value. In this test the UPS transfers to battery operation and the batteries are discharged to the low DC warning level. Based on the elapsed time and information about the load, the battery capacity can be calculated and the estimated runtime calibrated.

Schneider Electric recommends performing battery runtime calibration at start-up, when batteries are replaced, or when changes are made to the battery cabinets.

### **NOTICE**

#### **RISK OF EQUIPMENT DAMAGE**

- During a runtime calibration the batteries will be at a very low level and therefore not capable of supporting your system load in case of a input power failure.
- Batteries will be discharged to 10% capacity and this will result in a low battery runtime after the calibration.
- Repeated battery testing or calibration can affect the lifetime of the battery.

**Failure to follow these instructions can result in equipment damage.**

Prerequisites:

- Batteries must be 100% charged.
- The load percentage must be at least 10% and must not change more than 20% during test.
- The bypass supply must be available.
- The operation mode must be normal operation, ECOConversion, or ECO mode.
- The system operation mode must be inverter, ECOConversion, or ECO mode.

1. From the home screen on the display select **Tests > Runtime Calibration**.
2. Tap the **Start Runtime Calibration** button.

**NOTE:** If you wish to manually stop the runtime calibration, tap the **Abort Runtime Calibration** button.

## Perform an Annunciators Test

1. From the home screen on the display select **Tests > Annunciators**.
2. Tap the **Start** button to initiate the test.

During the annunciators test the LEDs on the display and the mimic diagram and the audible alarm are tested.


## Calibrate the Display

From the home screen on the display select **Tests > Display Calibration** and then select the calibration you want to perform.

- **Calibrate:** Tests and adjusts the touch screen target sensitivity.
- **Calibration Check:** Checks the calibration adjustments.

# 10" System Bypass Display


## 10" System Bypass Display Menu Tree (Option)



## Configuration from the 10" System Bypass Display (Option)


### Configure the Display Settings

1. From the home screen on the display select **Configuration > Display**.



2. Set the brightness of the display via the **Brightness** indicator. Tap **+** to increase the brightness and tap **-** to decrease the brightness.


3. Set the backlight timeout. Choose between **1, 2, 5, 10, 15,** or **30** minutes.
4. Set the language of the display.
5. Configure the network by tapping the **Network configuration** button and typing in the **IP Address, Mask,** and **Gateway.** Complete with **OK.**



6. Tap the home button to exit the configuration screen.

### Change the User Password

1. From the home screen on the display select **Configuration > Customer > Change Password.**



2. Type in **New Password** and **Confirm Password** and complete with **OK.**
3. Tap **Close** or the **X** button to exit the **User password reset** pop-up screen.
4. Tap the home button to exit the configuration screen.

## Change the System Names

1. From the home screen on the display select **Configuration > Customer > ID Setup**.

The screenshot shows a configuration screen with a top navigation bar containing a home icon and three tabs: 'Configuration', 'Customer', and 'ID Setup'. The 'ID Setup' tab is active. The screen is divided into four main sections, each with a title and a list of input fields:


- UPS (10 Characters):** Contains three input fields labeled 'UPS 1', 'UPS 2', and 'UPS 3'.
- Input (10 Characters):** Contains three input fields labeled 'Input 1', 'Input 2', and 'Input 3'.
- Output (14 Characters):** Contains one input field labeled 'System Output'.
- Bypass (18 Characters):** Contains three input fields labeled 'Maintenance Bypass', 'Bypass', and 'System Bypass'.

At the bottom right of the screen, there are two buttons: 'OK' and 'Cancel'.

2. The following names can be changed.
  - UPS
  - Input
  - System Output
  - Maintenance Bypass
  - Bypass
  - System Bypass
3. Tap **OK** to confirm your settings.
4. Tap the home button to exit the configuration screen.

### Configure the Output Distribution Breakers

1. From the home screen on the display select **Configuration > Customer > Output Setup**.



2. Select **Present** for the output distribution breakers that are available in the parallel system.
3. Select **Present** for the **Load Bank Breaker** if it is part of the parallel system and indicate whether the load bank breaker is **Upstream of SIB** or **Downstream of SIB**.
4. Tap **OK** to confirm your settings.
5. Tap the home button to exit the configuration screen.

## Operation Procedures from the 10" System Bypass Display (Option)

### Access Password-Protected Screens

**NOTE:** The default administrator username/password are admin/admin.

**NOTE:** The default user username/password are config/config.

1. When prompted for the password, tap the **Username** field to access the keyboard.
2. Tap the username field, type in your username, and tap **Enter**.
3. Tap the **Password** field, type in your password, and tap **Enter**.
4. Tap **Login**.
5. Tap **Close** or the **X** button to exit the **Login** pop-up screen.

### View the Parallel System Status

1. From the home screen on the display select **Status > Parallel System**.

2. Select the area for which you wish to see the status. Choose between:


**Measurements**

<b>Input Current (A)</b>	The present phase-to-phase input current in amperes (A).
<b>Output Current (A)</b>	The present phase-to-phase output current in amperes (A).
<b>Bypass Current (A)</b>	The present phase-to-phase bypass current in amperes (A).
<b>Number of Parallel UPS</b>	The total number of UPSs in the parallel system.
<b>Number of Redundant UPS</b>	The redundancy for the parallel system.
<b>Number of Redundant Power Cabinets per UPS</b>	The number of redundant power cabinets in each UPS.
<b>Output Total Apparent Power (kVA)</b>	The present total apparent output power (for all three phases) in thousands of Volt-Amps (kVA).
<b>Output Total Active Power (kW)</b>	The present total active output power (for all three phases) in kilowatts (kW).
<b>Output Total Load (%)</b>	The percentage of the UPS system capacity presently used across all phases. The load percentage for the highest phase load is displayed.

**Mimic Diagram**


<b>Mimic Diagram</b>	The mimic diagram shows the current status of the main parts of the UPS system: power sources, converters, bypass static switch and breakers, and it shows the power flow through the system.
----------------------	---

**NOTE:** You can click the UPS or the system bypass to get a more detailed mimic diagram.



**Communication Status**


<b>Communication Status</b>	The communication status diagram shows the communication status between the display and the UPSs of the parallel system.
-----------------------------	--



3. Tap the home button to exit the screens and return to the home screen.

### View System Bypass Status

1. From the home screen on the display select **Status > System Bypass**.



2. Tap the home button to exit the screens and return to the home screen.

### View UPS Status Information

1. From the home screen on the display select **Status > UPS X**.

## 2. Select the area for which you wish to see the status. Choose between:

**Input**

<b>Voltage (V) phase-to-neutral<sup>4</sup></b>	The present phase-to-neutral input voltage in volts (V).
<b>Current (A)</b>	The present input current from the AC utility power source per phase in amperes (A).
<b>Peak RMS Current (A)</b>	The maximum current for the latest 30 days.
<b>Apparent Power (kVA)</b>	The present apparent input power for each phase in kVA. Apparent power is the product of RMS (root mean square) volts and RMS amperes.
<b>Active Power (kW)</b>	The present active input power (or real power) for each phase in kilowatts (kW). Active power is the portion of power flow that, averaged over a complete cycle of the AC waveform, results in net transfer of energy in one direction.
<b>Power Factor</b>	The ratio of the active power to apparent power.
<b>Voltage (V) phase-to-phase</b>	The present phase-to-phase input voltage.
<b>Total Apparent Power (kVA)</b>	The present total apparent input power (for all three phases) in kVA.
<b>Total Active Power (kW)</b>	The present total active input power (for all three phases) in kW.
<b>Frequency (Hz)</b>	The present input frequency in hertz (Hz).
<b>Energy (kWh)</b>	The total energy consumption since the time of installation or since the number was reset.

**Output**

<b>Voltage (V) phase-to-neutral<sup>4</sup></b>	The phase-to-neutral output voltage at the inverter in volts (V).
<b>Current (A)</b>	The present output current for each phase in amperes (A).
<b>Peak RMS Current (A)</b>	The maximum current for the latest 30 days.
<b>Apparent Power (kVA)</b>	The present apparent output power for each phase in kVA. Apparent power is the product of RMS (root mean square) volts and RMS amperes.
<b>Active Power (kW)</b>	The present active output power (or real power) for each phase in kilowatts (kW). Active power is the portion of power flow that, averaged over a complete cycle of the AC waveform, results in net transfer of energy in one direction.
<b>Power Factor</b>	The present output power factor for each phase. Power factor is the ratio of active power to apparent power.
<b>Current Crest Factor</b>	The present output crest factor for each phase. The output crest factor is the ratio of the peak value of the output current to the RMS (root mean square) value.
<b>Current THD (%)</b>	The THD (total harmonic distortion) for each phase, as a percentage, for the present output current.
<b>Voltage (V) phase-to-phase</b>	The phase-to-phase output voltage at the inverter in volts (V).
<b>Total Apparent Power (kVA)</b>	The present apparent output power for each phase in thousands of Volt-Amps (kVA). Apparent power is the product of RMS (root mean square) volts and RMS amperes.
<b>Total Active Power (kW)</b>	The present total active output power (for all three phases) in kilowatts (kW).
<b>Load (%)</b>	The percentage of the UPS capacity presently used across all phases. The load percentage for the highest phase load is displayed.
<b>Neutral Current (A)<sup>1</sup></b>	The present output neutral current in amperes (A).
<b>Frequency (Hz)</b>	The present output frequency in hertz (Hz).
<b>Inverter Status</b>	The general condition of the inverter.
<b>PFC Status</b>	The general condition of the PFC.
<b>Energy (kWh)</b>	The total energy supplied since the time of installation or since the value was reset.

**Bypass**

<b>Voltage (V) phase-to-neutral<sup>4</sup></b>	The present phase-to-neutral bypass voltage (V).
<b>Current (A)</b>	The present bypass current for each phase, in amperes (A).

<sup>4</sup> Only applicable in systems with neutral connection.

<b>Peak RMS Current (A)</b>	The maximum current for the latest 30 days.
<b>Apparent Power (kVA)</b>	The present apparent bypass power for each phase in kVA. Apparent power is the product of RMS (root mean square) volts and RMS amperes.
<b>Active Power (kW)</b>	The present active bypass power for each phase in kilowatts (kW). Active power is the time average of the instantaneous product of voltage and current.
<b>Power Factor</b>	The present bypass power factor for each phase. Power factor is the ratio of active power to apparent power.
<b>Voltage (V) phase-to-phase</b>	The present phase-to-phase bypass voltage (V).
<b>Total Apparent Power (kVA)</b>	The present total apparent bypass power (for all three phases) in thousands of Volt-Amperes (kVA).
<b>Total Active Power (kW)</b>	The present total active bypass power (for all three phases) in kilowatts (kW).
<b>Frequency (Hz)</b>	The present bypass frequency in hertz (Hz).

**Battery**

<b>Voltage (V)</b>	The present battery voltage.
<b>Current (A)</b>	The present battery current in amperes (A). A positive current indicates that the battery is charging; a negative current indicates that the battery is discharging.
<b>Power (kW)</b>	The present DC power being drawn from the battery, in kilowatts (kW).
<b>Estimated Charge Level (%)</b>	The present battery charge, as a percentage of full charge capacity.
<b>Estimated Charge Time (h:mn)</b>	The estimated time, in minutes, until the batteries reach 100% charge.
<b>Runtime Remaining (h:mn)</b>	The amount of time in hours and minutes before the batteries reach the low-voltage shutdown level.
<b>Charger Mode</b>	The operation mode of the charger (Off, Float, Boost, Equalization, Cyclic, Test).
<b>Battery Status</b>	The general condition of the battery.
<b>Charger Status</b>	The general condition of the charger.
<b>Total Battery Capacity (Ah)</b>	The total capacity available from the available batteries.
<b>Battery Temperature C°</b>	The highest battery temperature from the connected temperature sensors.

**Temperature**

<b>Temperature</b>	Ambient temperature in degrees Celsius or Fahrenheit for the I/O cabinet and each power cabinet.
--------------------	--

**System**


<b>Output Voltage</b>	The phase-to-phase output voltage at the inverter in volts (V).
<b>Output Current</b>	The present output current for each phase in amperes (A).
<b>Output Frequency</b>	The present output frequency in hertz (Hz).
<b>Runtime Remaining</b>	The amount of time in hours and minutes before the batteries reach the low-voltage shutdown level.
<b>System Time</b>	The time of the UPS system.
<b>UPS Operation Mode</b>	The operation mode of the operated UPS.
<b>System Operation Mode</b>	The operation mode of the complete UPS system.
<b>Total Output Power</b>	The apparent and active power (or real power) output for each phase.
<b>Output Power</b>	The phase-to-phase apparent and active output power (or real power) for each phase.

**Mimic Diagram**

<b>Mimic Diagram</b>	The mimic diagram shows the current status of the main parts of the UPS: power sources, converters, bypass static switch and breakers, and it shows the power flow through the UPS.
----------------------	---

**Detailed View**

Detailed view	The detailed view shows the system with a status icon on each individual power cabinet and the actual number of redundant power cabinets. The detailed view also shows the apparent power and active power per phase.
---------------	---




3. Tap the home button to exit the screens and return to the home screen.

**Transfer the Parallel System from Normal to Requested Static Bypass Operation**

Please note that only the administrator can change operation mode.

1. From the home screen on the display select **Control**.



2. Tap the **Transfer to Requested Static Bypass** button.

**NOTE:** If the conditions for performing the transfer are not met, the button will be grayed out.

3. Verify that the **System Operation Mode** changes to **Requested Static Bypass**.

### Transfer the Parallel System from Requested Static Bypass to Normal Operation

Please note that only the administrator can change operation mode.

1. From the home screen on the display select **Control**.
2. Tap the **Transfer to Inverter Operation** button.  
**NOTE:** If the conditions for performing the transfer are not met, the button will be grayed out.
3. Verify that the **System Operation Mode** changes to **Inverter**.

### Connect to the 10" System Bypass Display Remotely

1. In Internet Explorer 10 or newer, type in the IP address of the display.
2. If requested, follow Active X installation instructions.
3. Select the **Monitoring** tab and then select **Web Gate > New Window** in the left pane.  
You now have access to the status and log information of the parallel system.
4. Log in with your username and password.




### Troubleshooting from the 10" System Bypass Display (Option)

#### View the Display Log

**NOTE:** This log is only related to the display operation and not to the operation of the UPS system.


1. From the home screen on the display select **Logs > Display**.



2. You can perform the following operations in the log:
  - a. Tap the arrows to browse through the list of events.
  - b. Tap the recycle bin button to clear the log.<sup>5</sup>
3. Tap the home button to exit the log.

### View the Parallel System Log

1. From the home screen on the display select **Logs > Parallel System**.




2. You can perform the following operations in the log:
  - a. Tap the arrows to browse through the list of events.
  - b. Tap the recycle bin button to clear the log.<sup>5</sup>

<sup>5</sup> This action is only available to the administrator.

3. Tap the home button to exit the log.

## View the Active Alarms

1. Tap the symbol in the top right corner of the screen.



2. You can perform the following operations on the **Active Alarms** screen:
  - a. Tap the arrows to browse through the list of active alarms.

The active alarms are colored according to the alarm level:

    - Green: No active alarms present
    - Blue: Informational alarm present
    - Yellow: Warning alarm present
    - Red: Critical alarm present
  - b. Tap the recycle bin button to clear the active alarms list.<sup>6</sup>
  - c. Tap the Acknowledge button to stop the flashing of the active alarms.
3. Tap the home button to exit the active alarms list.


<sup>6</sup> This action is only available to the administrator.

# Maintenance

## User-Replaceable Parts

### Replace the Top Filter


Rear View of the Front Door



1. Open the front door of the cabinet.
2. Turn the filter locks to release the filter.
3. Lift up the filter.
4. Take the replacement filter from the installation kit and install the new filter.
5. Turn the filter locks to fasten the filter.

## Replace the Three Bottom Filters

Rear View of the Front Door



1. Open the front door of the cabinet.
2. Turn the filter locks to release the filters.
3. Tilt the filters out and lift them up.
4. Take the replacement filters from the installation kit and install the new filters.
5. Turn the filter locks to fasten the filters.

# Troubleshooting

## Determine if you need a Replacement Part

To determine if you need a replacement part, contact Schneider Electric and follow the procedure below so that the representative can assist you promptly:

1. In the event of an alarm condition, scroll through the alarm lists, record the information, and provide it to the representative.
2. Write down the serial number of the unit so that you will have it easily accessible when you contact Schneider Electric.
3. If possible, call Schneider Electric from a telephone that is within reach of the display so that you can gather and report additional information to the representative.
4. Be prepared to provide a detailed description of the problem. A representative will help you solve the problem over the telephone, if possible, or will assign a return material authorization (RMA) number to you. If a module is returned to Schneider Electric, this RMA number must be clearly printed on the outside of the package.
5. If the unit is within the warranty period and has been started up by Schneider Electric, repairs or replacements will be performed free of charge. If it is not within the warranty period, there will be a charge.
6. If the unit is covered by a Schneider Electric service contract, have the contract available to provide information to the representative.

## Find the Serial Numbers

**NOTE:** If the display is not available, the serial number can also be found on a label in each specific cabinet.

1. From the home screen on the display interface select **About > UPS**.
2. On the first page note down the serial number of the I/O cabinet and have it ready for customer support.
3. Press the arrow to go to the next page and note down the serial numbers of the power cabinets and have them ready for customer support.

## Return Parts to Schneider Electric

Call Schneider Electric to obtain an RMA number.

To return an inoperable part to Schneider Electric, pack the module in the original shipping materials, and return it by insured, prepaid carrier. The customer support representative will provide the destination address. If you no longer have the original shipping materials, ask the representative about obtaining a new set. Pack the module properly to avoid damage in transit. Never use styrofoam beads or other loose packaging materials when shipping a module. The module may settle in transit and become damaged. Enclose a letter in the package with your name, RMA number, address, a copy of the sales receipt, description of the problem, a phone number, and a confirmation for payment (if necessary).

**NOTE:** Damages sustained in transit are not covered under warranty.





Schneider Electric  
35 rue Joseph Monier  
92500 Rueil Malmaison  
France

+ 33 (0) 1 41 29 70 00

[www.schneider-electric.com](http://www.schneider-electric.com)

As standards, specifications, and design change from time to time,  
please ask for confirmation of the information given in this publication.

© 2016 – 2017 Schneider Electric. All rights reserved.

990-5452C-001